DIMENSIONAL DRAWING: ET6554L











IO CONNECTIONS



DIMENSIONS ARE IN MILLIMETERS

ēlo

MS603262
DATE: 08/01/2024
REV: A

DIMENSIONAL DRAWING: ET6554L

COMPUTE MODULE MOUNTING







BRIGHTSIGN COMPUTE MODULE MOUNTING INSTRUCTIONS:

1. ALIGN COMPUTE MODULE EDGE WITH HORIZONTAL MARKING
2. CENTER COMPUTE MODULE USING VERTICAL MARKINGS
3. INSTALL M4 SCREWS THROUGH DEVICE (MAX SCREW DEPTH INTO ET6554L = 5mm)
4. CONNECT POWER AND I/O CABLES FROM COMPUTER TO 6554L

DIMENSIONS ARE IN MILLIMETERS

ēlo

MS603262
DATE: 08/01/2024
REV: A

DIMENSIONAL DRAWING: ET6554L

LOW-PROFILE WALL MOUNT KIT P/N E727774
SEE PAGE 4 FOR WALL SIDE LAYOUT



DIMENSIONS ARE IN MILLIMETERS

MS603262
DATE: 08/01/2024
REV: A

DIMENSIONAL DRAWING: ET6554L

LOW-PROFILE WALL MOUNT KIT P/N E727774
WALL SIDE LAYOUT







DIMENSIONS ARE IN MILLIMETERS

ēlo

MS603262
DATE: 08/01/2024
REV: A